Body CameraOperating Instructions V101.0



Note: Please read the manual carefully before using.

Please abide by local laws and do not use this product for any illegal purpose. All consequences shall be borne by yourself.

-1-



Button introduction

Ů −Power button

★ -Motion detection record

☐ -Video

ి -Indicator light

R -Reset button

■D/D-Infrared night vision lights switch

- 2 -

Note:

- 1) No memory card is inserted, the red light flashes for 10 seconds, and then the device will shut down automatically.
- 2) The device memory card must be 8GB or above. Data can't be saved normally in memory less than 8GB
- 3) After power on, it will automatically enter video mode or motion detection mode.

One. Product parameters:

Video format: AVI
Video coding: M-JPEG
Video resolution: 1920*1080
Video frame rate: 30fps
Motion detection record: Support
Battery capacity: about 1200mAh
Record time: about 600 minutes
Charge voltage: DC-5V 1A
Storage support: 8GB-128GB

Transmission speed: USB 2.0 Interface type: Type-C Storage temperature: -10-40℃ Working humidity: 15-85% Rh9

Two. Product operation:

The following operation is based on inserting the TF card correctly.

- 3 -

1. Charging:

This device has built-in rechargeable lithium battery. When the device is short of power, it can be charged in the following ways:

- 1). Connect the 5V-1A charger;
- 2). Connect the mobile power bank (5V-1A);

Note: the red and blue lights flash at the same time when charging. When fully charged, the red and blue lights are on.

2. Power on&Power off

On: press the power button for 2 seconds.
Off: press the power button for 2 seconds to turn off the device.

3. Video

Video: Push the button to position, and press the power button for 2 seconds. The device is power on, the red and blue light is on, then the blue light is off, and the red light flashes twice and goes out to enter the video recording.

Save:While recording, click the power button once to stop and save the recording, the red light will be on, and the device will return to standby mode.

One paragraph,5 minutes, support loop recording.

- 4 -

4. Motion Detection Mode:

When power off, push the button to position.

After power on, it will automatically enter the motion detection mode.

In this mode, the blue light flashes fast, the device is at the detecting state. Once it detects any moving objects within the range, the blue light flashes slowly and the device enters the video recording. After 2 minutes, the recording will be saved automatically. If there is no moving object, the device will return to the detecting state.

Exit: Click the power button once to stop and save the video, return to standby mode, the blue light is on.

Note:

Motion detection record, one paragraph, 2 minutes.

Detecting state:blue indicator flashes fast; Recording state:blue indicator flashes slowly.

5. Infrared night vision lights switch:

- 5 -

You can turn on or off based on your needs.

 $\exists 0$: Turn on; 0: Turn off.

6. Record with charging:

When the device is power off, connect the device into the charger or power bank, and the device will enter to the video mode or motion detection mode.

Click the power button, the red and blue lights flash at the same time, the device is under the charging state.

Note: The device can't enter the video mode when connecting into the computer.

7. Reset

In case of system error or malfunctioning, need to reset the device.

Method:

Press the reset $\mathsf{button}\,(\mathsf{R})$ to reset.

8. Time setting:

- 1.) Upon power on, the device will generate a time file named "TIME.TXT" in the system.
- 2.) TURN OFF the device and connect it to a computer.
- 3.) Locate the "TIME.TXT" file, set the desired time using format 2025–05-01 18:18:18 Y and save the file.

4.) Disconnect the device from the computer then turn on the device. The time set is then complete.

If you want to cancel the time stamp.Modify "Y" in "TIME.TXT" file to "N" to disable the time display.The reference format is as follows:

1:2025-05-01 18:18:18 Y (with time watermark display)

2:2025-05-01 18:18:18 N (no time watermark display)

Three. Indicator light description

Red light flashes twice and goes off	Recording state
Red light flashes fast	No TF card detected
Blue light flashes	Motion detection mode
Red and blue lights flash at the same time	Charging
Red and blue lights are on at the same time	Full charged

Disclaime

- 1. The usage of this device is subject to the relevant national laws and regulations, DO NOT use this product for any illegal activities.
- 2.DO NOT point the camera lens to the direct sun light or permanent damage may occur.
- 3.Keep away from fire. Never expose the device to any fire source.
- 4.DO NOT disassemble and modify. Doing so causes the risk of electric shock, burn injury and other health related hazard.
- 5.DO NOT let water, liquids, or foreign matter get inside the device. Extra precaution is advised where it is raining, snowing, near the ocean or other form of water. In case any of the symptoms are present, turn off the device immediately and contact us for further support.
- 6.DO NOT drop the device or permanent damage may occur.

-6- -7-