


WIFI Camera Manual

V2.1.1



Note:

1.Power button;

2.M button: Press M button 3 seconds and release it to restore the factory setting mode

Note:

Input Voltage : DC:5V-1A/2A

LED State:

Blue light slow flashing - not connect to network;

Blue light fast flashing - After setting WiFi, connecting to the network;

Blue light on - WiFi setting successful;

Red light -Charging indicator. When charging, the red light is on; Fully charged, the red light goes out.

One.APP Download

You can download the app by scanning the QR code below.

APP Name:LLCam



Apple system phone can search the APP in App Store to download;
Android phones can be downloaded by scanning the QR code.


Two. Connection steps:

1. Open the app, register and log in.
2. Click on "Add Device"; the app will search for surrounding device, and you select the right device, click "Add".


Note:

Before adding, open your phone "Bluetooth information Permission" firstly.

If no device, you can press the "M" button 3 seconds to reset it.




Or you want to add the device manually, Please select the "Battery camera".



3. "Configure Device Network"->Confirm "Your WIFI information".

Note:

You must select the network(2.4G Only) to be connected.



4. One minute later, the device will be connected to the network.

If you input the wrong password during operating, the device will not connect to the network successfully. You can reset the device to the factory setting by pressing the "M" button and releasing it. Operate the device from step "1" again.

Common Problem:

1. About the network name (router name), please use letters and numbers, not special characters, such as ". " "- " "/" and so on.

2. The device is offline.

- 1) The device is within 5 meters from the router or network. Within 5 meters, the network connection is better.

- 2) The device supports WIFI 2.4GHz, not 5GHz. You can set it in router for 2.4GHz hotspot.

3. Restore device to factory settings

Please press the reset button 3 seconds and release it.

4. No video files

A: Please check whether the memory card is inserted and is right. You can check it in APP.